

2000 - Early 2007 GM 38" Frame Install Kit

Kit Includes:

5/8"-11 x 2" Bolts x 10

5/8"-11 Nuts x 10


5/8" Lock Washers x 10

5/8" Flat Washers x 20

3"Deep x 4" Tall x 7" Wide 7" Angle x2



2 1/2" Tall x 8" Wide 8" Flats x2



2 1/2" Tall x 50" Wide 50" Bars x2
Holes at 47 1/4" Centers

